

# **TPS259250-61EVM: Evaluation Module for TPS259250/61**

This user's guide describes the evaluation module (EVM) for the TPS259250/61. The TPS259250/61 devices are simple 5-V/12-V eFuse Protection Switches with, overcurrent and in-rush current protection features.

## **Contents**

1	Introduction .....	2
1.1	EVM Features .....	2
1.2	EVM Applications .....	2
2	Description .....	3
3	Schematics .....	4
4	General Configurations .....	5
4.1	Physical Access .....	5
4.2	Test Equipment and Set Up .....	5
4.3	Test Setup and Procedures .....	6
5	EVM Assembly Drawings and Layout Guidelines.....	10
5.1	PCB Drawings .....	10
6	Bill of Materials (BOM).....	12

## **List of Figures**

1	TPS259250-61EVM Schematic.....	4
2	EVM Setup With Test Equipment.....	6
3	J3 = "ILIM-LO" Current Limit (2.1 A) Test-Latched Feature (CH1).....	9
4	J7 = "ILIM-LO" Current Limit (2.1 A) Test Auto-Retry (CH2).....	9
5	Top Side Placement .....	10
6	Top Layer .....	10
7	Bottom Layer.....	11

## **List of Tables**

1	TPS259250/61 EVM Options and Settings.....	3
2	Input and Output Connector Functionality .....	5
3	Test Points Description .....	5
4	Jumper and LED Descriptions .....	5
5	Power Supply Setting for TPS259250-61EVM.....	7
6	Default Jumper Setting for TPS259250-61EVM .....	7
7	TPS259250-61EVM DMM Readings at Different Test Points .....	7
8	TPS259250-61EVM Oscilloscope Setting for Current Limit Test.....	8
9	TPS259250-61EVM Jumper Setting for Current Limits.....	8
10	TPS259250-61EVM Bill of Materials .....	12

## 1 Introduction

The TPS259250-61EVM allows reference circuit evaluation of TI's TPS259250/61 devices. The TPS259250 and TPS259261 devices are simple 5-V/12-V eFuse Protection Switches and are available with latching and auto-retry operation, respectively.

### 1.1 EVM Features

General TPS259250-61EVM features include:

- 4.5-V to 5.5-V (TYP) operation (TPS259250DRCR):
  - CH1 rising input voltage turn-on threshold – 4.3 V (TYP)
  - CH1 rising output voltage clamp threshold (OVP) – 6.1 V (TYP)
  - CH1 falling input voltage turn-off threshold (UVLO) – 4.2 V (TYP)
- 4.5-V to 13.5-V (TYP) operation (TPS259261DRCR)
  - CH2 Rising input voltage turn-on threshold – 4.3 V (TYP)
  - CH2 Rising output voltage clamp threshold (OVP) – 15 V (TYP)
  - CH2 Falling input voltage turn-off threshold (UVLO) – 4.2 V (TYP)
- 2.1 A to 5.1 A programmable current limit
- Programmable  $V_{OUT}$  slew rate
- Latched-off TPS259250DRCR
- Auto-retry TPS259261DRCR
- Push button RESET signal
- On-board transorb for overvoltage input protection
- Common diode at output prevents a negative spike when the load is removed
- Reverse polarity protection feature

### 1.2 EVM Applications

The TPS259250/61 provides the following EVM applications:

- White goods/appliances
- HDD and SSD drives
- Thunderbolt host ports
- Hot-swap boards
- PCI/PCIe Cards
- Servers
- Set-top boxes, DVD, and Blu-ray™ units

## 2 Description

The TPS259250-61EVM enables full evaluation of the TPS259250/61 devices. The EVM supports two versions (latched and auto- retry) of the devices on two channels (CH1 and CH2, respectively). Input power is applied at J1 (CH1) and J6 (CH2) while J2 (CH1) and J8 (CH2) provide the output connection to the load. Refer to the schematic in [Figure 1](#) and the EVM test setup in [Figure 2](#).


D1/C1 (CH1) and D4/C8 (CH2) provide input protection for TPS259250/61 (U1 and U2, respectively) while D2/C2 (CH1) and D6/C6 (CH2) provide output protection and inrush current demand from the load. S1 and S2 allow U1 and U2, respectively, to be RESET or disabled. A power good (PG) indicator is provided by D3 for CH1 and CH2.

**Table 1. TPS259250/61 EVM Options and Settings**

Part Number	EVM Function	Channel	Vin Range	UVLO	OVP	Current Limit			Fault Response
						Lo Setting	No Jumper	Hi Setting	
TPS259250-61EVM	5-V/12-V eFuse protection switches	CH1	4.5 V–5.5 V	4.2 V	6.1 V	2.1 A	5.1 A	3.7 A	Latched
		CH2	4.5 V–13.5 V	4.2 V	15 V	2.1 A	5.1 A	3.7 A	Auto-retry

### 3 Schematics

Figure 1 illustrates the TPS259250-61EVM schematic.



\* D1,D2,D4,D5 can be removed for non-inductive connections

Figure 1. TPS259250-61EVM Schematic

## 4 General Configurations

### 4.1 Physical Access

Table 2 lists the TPS259250-61EVM input and output connector functionality, Table 3 describes the test point availability, and Table 4 describes the jumper functionality.

**Table 2. Input and Output Connector Functionality**

Connector	Label	Description
J1	CH1	VIN1(+), GND(-)
J2		VOU1(+),GND(-)
J6	CH2	VIN2(+), GND(-)
J8		VOU2(+),GND(-)

**Table 3. Test Points Description**

Channel	Test Points	Label	Description
CH1	TP1	VIN1	CH1: Input power supply to the EVM
	TP2	EN1	CH1: Active high enable and undervoltage input
	TP3	VOU1	CH1: Output from the EVM
	TP7	GND	GND
	TP8	GND	GND
	TP6	GND1	GND1(IC GND)
	TP9	GND1	GND1(IC GND)
CH2	TP10	VIN2	CH2: Input power supply to the EVM
	TP11	EN2	CH2: Active high enable and undervoltage input
	TP12	VOU2	CH2: Output from the EVM
	TP4	GND	GND
	TP14	GND	GND
	TP5	GND1	GND1(IC GND)
	TP13	GND1	GND1(IC GND)

**Table 4. Jumper and LED Descriptions**

Jumper	Label	Description
J3	LIM HI –LIM-LO	CH1 current setting
J7	LIM HI –LIM-LO	CH2 current setting
D4 (Green)	D3	CH1 and CH2 power good indicator This LED turns on from: VOU1 – if jumper is installed in position 2-3 VOU2 – if jumper is installed in position 1-2

### 4.2 Test Equipment and Set Up

#### 4.2.1 Power Supplies

One adjustable power supply: 0-V to 20-V output, 0-A to 6-A output current limit.

#### 4.2.2 Meters

One digital multimeter (DMM), minimum, needed and may require more if simultaneous measurements are needed.

### 4.2.3 Oscilloscope

A DPO2024 or Lecroy 424 oscilloscope, or equivalent, three 10x voltage probes, and a DC current probe.

### 4.2.4 Loads

One resistive load, or equivalent, which can tolerate up to 6-ADC load at 12 V and at 5 V and are capable of the output short.

## 4.3 Test Setup and Procedures

Figure 2 shows a typical test setup for the TPS259250-61EVM. Connect J1/J6 to the power supply and J2/J8 to the load.




Figure 2. EVM Setup With Test Equipment

### 4.3.1 Test Procedure

- Set the power-supply output  $V_{IN}$  to 0 V.
- Turn on the power supply and set the output voltage and current limit according to [Table 5](#):

**Table 5. Power Supply Setting for TPS259250-61EVM**

EVM	Channel	Voltage Set Point	Power Supply Current Limit
TPS259250-61EVM	CH1(J1)	5 $\pm$ 0.1 VDC	6 A $\pm$ 0.25 ADC
	CH2(J6)	12 $\pm$ 0.2 VDC	

- Turn off the power supply. Hook up CH1 and CH2 of the TPS259250-61EVM assembly as shown in [Figure 1](#).
- The default EVM jumper setting is shown in [Table 6](#):

**Table 6. Default Jumper Setting for TPS259250-61EVM**

J3(CH1)	J5 (CH1)	J7 (CH2)	J9(CH2)	J4(VOUT1)
2-3	Install	2-3	Install	2-3

- CH1 and CH2 can be tested one by one for TPS259250-61EVM.
- Ensure that the output load is disabled and the power supply is set properly for the DUT. Connect the negative probe of DMM to TP7 (CH1) or TP4 (CH2) test points and positive probe as in [Table 3](#). Turn on the power supply. Verify that the voltages shown in [Table 3](#) are obtained.
- Connect the 2-A load current at J2 and J8.

**Table 7. TPS259250-61EVM DMM Readings at Different Test Points**

Voltage Test on (CH1)	Measured Voltage Reading	Voltage Test on (CH2)	Measured Voltage Reading
VIN1 (TP1)	5 $\pm$ 0.2 VDC	VIN2 (TP10)	12 $\pm$ 0.5 VDC
EN1 (TP2)	4.5 $\pm$ 0.2 VDC	EN2 (TP11)	6.4 $\pm$ 0.5 VDC
VOUT1 (TP3)	5 $\pm$ 0.2 VDC	VOUT2 (TP12)	12 $\pm$ 0.5 VDC

#### 4.3.1.1 For CH1 (J1)

- Press the EVM RST switch, S1, and verify that the voltage at VOUT1 (TP3) starts falling below 5 V. Release S1.
- Reduce the input voltage on VIN1 (TP1) and monitor VOUT1. Verify that VOUT1 (TP3) starts falling and is fully turned off when VIN1 (TP1) reaches 4.3 V ( $\pm$ 0.3 V).
- Increase the input voltage on VIN1 and monitor VOUT1. Verify that VOUT1 (TP3) starts increasing and clamped at 6.1 V ( $\pm$ 0.4V), VIN1 exceeds 6.1 V.
- Adjust the power supply voltage to 5 V.
- Turn off the power supply.

#### 4.3.1.2 For CH2 (J6)

- Press the EVM RST switch, S2, and verify that the voltage at VOUT2 (TP12) starts falling below 12 V. Release S1.
- Reduce the input voltage on VIN2 (TP10) and monitor VOUT2. Verify that VOUT2 (TP12) starts falling and is fully turned off when VIN2 (TP10) reaches 4.3 V ( $\pm 0.3V$ ).
- Increase the input voltage on VIN2 and monitor VOUT2. Verify that VOUT2 starts increasing and clamped at 15.1 V ( $\pm 0.4V$ ), VIN1 exceeds 15.1 V.
- Adjust the power supply voltage to 12 V.
- Turn off the power supply.

#### 4.3.1.3 Current Limit Test

- Verify all three current limits (CH1 and CH2, with only 1 channel powered at a time) and verify the latch and auto-retry feature. Setup the oscilloscope as shown in [Table 8](#).

**Table 8. TPS259250-61EVM Oscilloscope Setting for Current Limit Test**

Oscilloscope Setting	CH1 Probe Points	CH2 Probe Points
Channel 1 = 5 V/div	TP3 = VOUT1	TP12 = VOUT2
Channel 2 = 5 V/div	TP1 = VIN1	TP10 = VIN2
Channel 4 = 2 A/div	Input current into J1 +ve wire	Input current into J6 +ve wire
Trigger source = Channel 4		
Trigger level = 2.5 A $\pm 0.1$ A		
Trigger polarity = +ve		
Trigger Mode = Single Sequence		
Time base	400 ms/div	100 ms/div

---

**NOTE:** If an electronic load is used, ensure that the output load is set to constant-resistance mode and not constant-current mode.

---

**NOTE:** Measuring current limit values on the oscilloscope can easily cause 8% error from anticipated values listed in [Table 9](#).

---

- The jumper settings for the different current limit test are shown in [Table 9](#).

**Table 9. TPS259250-61EVM Jumper Setting for Current Limits**

Jumper Position		Load Current Limit
J3 (CH1)	J7 (CH2)	
2-3 (ILIM LO)	2-3 (ILIM LO)	2.1 A $\pm 0.2$ A
1-2 (ILIM HI)	1-2 (ILIM HI)	3.7 A $\pm 0.3$ A
No Jumper	No Jumper	5.1 A $\pm 0.5$ A



- Set the output load at  $0.5 \pm 0.1 \Omega$  on CH1 and then enable the load. Turn on the VIN1 power supply, verify that input current is limited as per the setting in Table 9 and the device is in latched mode, as shown in Figure 3. The level of the current pulse should match with the load current limit (based on the respective jumper setting) as per Table 9.




Figure 3. J3 = "ILIM-LO" Current Limit (2.1 A) Test-Latched Feature (CH1)

- Set the output load at  $1.0 \pm 0.5 \Omega$  on CH2 and then enable the load. Turn on the VIN2 power supply, verify that input/output current is limited as per the setting in Table 9 and the device is in auto-retry mode, as shown in Figure 4. The level of the current pulse should match with the load current limit (based on the respective jumper setting) as per Table 9.




Figure 4. J7 = "ILIM-LO" Current Limit (2.1 A) Test Auto-Retry (CH2)

- Set the input power supply to zero volts and disconnect all equipment from the DUT.

## 5 EVM Assembly Drawings and Layout Guidelines

### 5.1 PCB Drawings

Figure 5 through Figure 7 show component placement and layout of the EVM.




Figure 5. Top Side Placement




Figure 6. Top Layer




Figure 7. Bottom Layer

## 6 Bill of Materials (BOM)

Table 10 lists the BOM for this EVM.

**Table 10. TPS259250-61EVM Bill of Materials<sup>(1)</sup>**

Designator	Quantity	Value	Description	PackageReference	PartNumber	Manufacturer	Alternate PartNumber	Alternate Manufacturer
!PCB	1		Printed Circuit Board		PWR639	Any		
C1, C2, C6, C8	4	1uF	CAP, CERM, 1uF, 25V, +/-10%, X5R, 0805	0805	08053D105KAT2A	AVX	-	-
D1, D4	2	15V	Diode, TVS, Bi, 15V, 600W, SMB	SMB	SMBJ15CA	Littelfuse		
D2, D5	2	0.47V	Diode, Schottky, 30V, 1A, SOD-123	SOD-123	MBR130T1G	ON Semiconductor	Equivalent	Any
D3	1	Green	LED, Green, SMD	Power TOPLED w/lens	LT E63C-CADB-35-L-Z	OSRAM	-	-
H9, H10, H11, H12	4		Bumpon, Cylindrical, 0.312 X 0.200, Black	Black Bumpon	SJ61A1	3M		
J1, J2, J6, J8	4		Terminal Block, 2x1, 5.08mm, TH	10.16x15.2x9mm	282841-2	TE Connectivity		
J3, J4, J7	3	1x3	Header, TH, 100mil, 1x3, Gold plated, 230 mil above insulator	PBC03SAAN	PBC03SAAN	Sullins Connector Solutions	Equivalent	Any
J5, J9	2		Header, 100mil, 2x1, Gold, TH	Sullins 100mil, 1x2, 230 mil above insulator	PBC02SAAN	Sullins Connector Solutions		
Q1, Q2	2	20V	MOSFET, N-CH, 20V, 10A, SON 2x2mm	SON 2x2mm	CSD15571Q2	Texas Instruments		None
R1, R6	2	1.00Meg	RES, 1.00 M, 1%, 0.1 W, 0603	0603	CRCW06031M00FKEA	Vishay-Dale		
R2, R7	2	45.3k	RES, 45.3 k, 1%, 0.1 W, 0603	0603	CRCW060345K3FKEA	Vishay-Dale		
R4, R5, R9	3	100k	RES, 100k ohm, 1%, 0.1W, 0603	0603	CRCW0603100KFKEA	Vishay-Dale		
S1, S2	2		Switch, Push Button, SMD	2.9x2x3.9mm SMD	SKRKAEE010	Alps	Equivalent	Any
SH-J3, SH-J4, SH-J5, SH-J7, SH-J9	5	1x2	Shunt, 100mil, Gold plated, Black	Shunt	969102-0000-DA	3M	SNT-100-BK-G	Samtec
TP1, TP3, TP10, TP12	4	Red	Test Point, TH, Multipurpose, Red	Keystone5010	5010	Keystone	Equivalent	Any
TP2, TP11	2	White	Test Point, TH, Multipurpose, White	Keystone5012	5012	Keystone	Equivalent	Any
TP4, TP7, TP8, TP14	4	SMT	Test Point, Compact, SMT	Testpoint_Keystone_Compact	5016	Keystone		
TP5, TP6, TP9, TP13	4	Black	Test Point, Multipurpose, Black, TH	Black Multipurpose Testpoint	5011	Keystone		
U1	1		Simple 5V eFuse Protection Switches, DRC0010J	DRC0010J	TPS259250DRCR	Texas Instruments	TPS259250DRCT	Texas Instruments
U2	1		Simple 5V eFuse Protection Switches, DRC0010J	DRC0010J	TPS259261DRCR	Texas Instruments	TPS259261DRCT	Texas Instruments
C3, C7	0	1uF	CAP, CERM, 1uF, 25V, +/-10%, X5R, 0805	0805	08053D105KAT2A	AVX	-	-
C4, C5, C9, C10	0	1000pF	CAP, CERM, 1000pF, 100V, +/-20%, X7R, 0603	0603	06031C102MAT2A	AVX	-	-
FID1, FID2, FID3	0		Fiducial mark. There is nothing to buy or mount.	Fiducial	N/A	N/A		
R3, R8	0	10k	RES, 10.0k ohm, 1%, 0.1W, 0603	0603	CRCW060310K0FKEA	Vishay-Dale	Equivalent	Any

<sup>(1)</sup> Unless otherwise noted in the alternate part number or alternate manufacturer columns, all parts may be substituted with equivalents.

## STANDARD TERMS AND CONDITIONS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, or documentation (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms and conditions set forth herein. Acceptance of the EVM is expressly subject to the following terms and conditions.
  - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms and conditions that accompany such Software
  - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
  - 2.1 These terms and conditions do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
  - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for any defects that are caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI. Moreover, TI shall not be liable for any defects that result from User's design, specifications or instructions for such EVMs. Testing and other quality control techniques are used to the extent TI deems necessary or as mandated by government requirements. TI does not test all parameters of each EVM.
  - 2.3 If any EVM fails to conform to the warranty set forth above, TI's sole liability shall be at its option to repair or replace such EVM, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.
3. *Regulatory Notices:*
  - 3.1 *United States*
    - 3.1.1 *Notice applicable to EVMs not FCC-Approved:*

This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.
    - 3.1.2 *For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:*

### CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Interference Statement for Class A EVM devices

*NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.*

## FCC Interference Statement for Class B EVM devices

*NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### 3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210

#### Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

#### Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur

### 3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see [http://www.tij.co.jp/lstds/ti\\_ja/general/eStore/notice\\_01.page](http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page) 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。  
[http://www.tij.co.jp/lstds/ti\\_ja/general/eStore/notice\\_01.page](http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page)

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan may not be certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, not certified to Technical Regulations of Radio Law of Japan, User is required by Radio Law of Japan to follow the instructions below with respect to EVMs:

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】 開発キットの中には技術基準適合証明を受けていないものがあります。技術適合証明を受けていないものご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。日本テキサス・インスツルメンツ株式会社  
東京都新宿区西新宿 6 丁目 2 4 番 1 号  
西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see [http://www.tij.co.jp/llds/ti\\_ja/general/eStore/notice\\_02.page](http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_02.page)  
電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。[http://www.tij.co.jp/llds/ti\\_ja/general/eStore/notice\\_02.page](http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_02.page)

#### 4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

#### 4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*
- 6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY WRITTEN DESIGN MATERIALS PROVIDED WITH THE EVM (AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.
- 6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS AND CONDITIONS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT MADE, CONCEIVED OR ACQUIRED PRIOR TO OR AFTER DELIVERY OF THE EVM.
7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS AND CONDITIONS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.
8. *Limitations on Damages and Liability:*
- 8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS AND CONDITIONS OR THE USE OF THE EVMS PROVIDED HEREUNDER, REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN ONE YEAR AFTER THE RELATED CAUSE OF ACTION HAS OCCURRED.
- 8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY WARRANTY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS AND CONDITIONS, OR ANY USE OF ANY TI EVM PROVIDED HEREUNDER, EXCEED THE TOTAL AMOUNT PAID TO TI FOR THE PARTICULAR UNITS SOLD UNDER THESE TERMS AND CONDITIONS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM AGAINST THE PARTICULAR UNITS SOLD TO USER UNDER THESE TERMS AND CONDITIONS SHALL NOT ENLARGE OR EXTEND THIS LIMIT.
9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.
10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2015, Texas Instruments Incorporated



## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

### Products

Audio	<a href="http://www.ti.com/audio">www.ti.com/audio</a>
Amplifiers	<a href="http://amplifier.ti.com">amplifier.ti.com</a>
Data Converters	<a href="http://dataconverter.ti.com">dataconverter.ti.com</a>
DLP® Products	<a href="http://www.dlp.com">www.dlp.com</a>
DSP	<a href="http://dsp.ti.com">dsp.ti.com</a>
Clocks and Timers	<a href="http://www.ti.com/clocks">www.ti.com/clocks</a>
Interface	<a href="http://interface.ti.com">interface.ti.com</a>
Logic	<a href="http://logic.ti.com">logic.ti.com</a>
Power Mgmt	<a href="http://power.ti.com">power.ti.com</a>
Microcontrollers	<a href="http://microcontroller.ti.com">microcontroller.ti.com</a>
RFID	<a href="http://www.ti-rfid.com">www.ti-rfid.com</a>
OMAP Applications Processors	<a href="http://www.ti.com/omap">www.ti.com/omap</a>
Wireless Connectivity	<a href="http://www.ti.com/wirelessconnectivity">www.ti.com/wirelessconnectivity</a>

### Applications

Automotive and Transportation	<a href="http://www.ti.com/automotive">www.ti.com/automotive</a>
Communications and Telecom	<a href="http://www.ti.com/communications">www.ti.com/communications</a>
Computers and Peripherals	<a href="http://www.ti.com/computers">www.ti.com/computers</a>
Consumer Electronics	<a href="http://www.ti.com/consumer-apps">www.ti.com/consumer-apps</a>
Energy and Lighting	<a href="http://www.ti.com/energy">www.ti.com/energy</a>
Industrial	<a href="http://www.ti.com/industrial">www.ti.com/industrial</a>
Medical	<a href="http://www.ti.com/medical">www.ti.com/medical</a>
Security	<a href="http://www.ti.com/security">www.ti.com/security</a>
Space, Avionics and Defense	<a href="http://www.ti.com/space-avionics-defense">www.ti.com/space-avionics-defense</a>
Video and Imaging	<a href="http://www.ti.com/video">www.ti.com/video</a>

### TI E2E Community

[e2e.ti.com](http://e2e.ti.com)